






ZNAKOVANJE STAJAL BROJNOVAČNO		ZNAKOVANJE STAJAL BROJNOVAČNO	
broj	oznaka	broj	oznaka
1	012	615	30858
2	012	666	30528
3	065	956	46708
4	012	616	61666
5	012	666	32366
6	065	1956	35766
7	065	256	14566
8	012	256	17566
9	065	386	21666
10	012	326	30766
11	012	326	26866
12	065	256	23266
13	012	256	17766
14	065	386	21866
15	012	566	31466
16	012	386	29666
17	065	1956	39766
18	065	256	13266
19	012	486	62766
20	012	486	62766
21	065	1956	21966
22	012	356	47166
23	065	386	18666

UWAGA:
- stal żebrowana - A-III,
- beton B20,
- balustrada wysokości 110cm

[illegible]